

EXPONA Design Flooring

**EXPONA
COMMERCIAL**

Supplier

Wet adhesives

Ardex GmbH

AF 2224
AF 140

**EXPONA
DESIGN**

Bostik Findley GmbH

Power Elastic

**EXPONA
DOMESTIC**

Forbo Erfurt GmbH

528 Eurostar Allround
643 Eurostar Fibre

Kiesel Bauchemie GmbH & Co. KG

Okatmos star 110

Mapei GmbH

Ultrabond Eco V4SP
Ultrabond Eco VS 90

PCI Augsburg GmbH

PKL 326

Schönox GmbH

Durocoll

STAUF Klebstoffwerk GmbH

STAUF D50

Thomsit, A brand of PCI

K 188 S

Uzin Utz AG

KE 66

Wakol Chemie

D 3318

Wulff GmbH & Co.

Supra-Strong, Multi-Strong
Ultra-Strong

The adhesives shown here require a consistently absorbent base.

The design floorcovering has to be rolled or rubbed down carefully after it is installed.

All the adhesives that we recommend must be used in accordance with the respective manufacturer's specifications.

Only those adhesives are suitable for the application and use.

Any adhesives that are not listed in this recommended list have not been tested. They have not been tested for compatibility with our products.

Note:

A thermosetting resin adhesive must be used when installing design floorcoverings in conservatories or rooms with large banks of windows with a high level of solar radiation.